

CLEMENT

creating light...beautifully™

Clement Conservation Rooflights Care & Warranty

Maintaining Your Rooflight

The following should be carried out on a regular basis:

1. Open and shut the rooflight.
2. Clean down the paint surface at least twice a year using warm water and a drop of washing up liquid. Please note that polluted environments will require more intensive maintenance.
3. Keep the weather stripping clean by removing all grime.
4. Ensure the working parts remain dust free and are regularly lubricated.
5. If you plan to install the rooflight in a marine environment, please contact us on 01428 643393.

Warranty Information

Clement Conservation Rooflights come with a ten year warranty on the paint surface, a five year warranty for glass unit failure and a one year warranty for fittings. In the event of a problem occurring, please contact us within 48 hours.

Please read our Terms & Conditions thoroughly. A copy is available upon request.